

WASH & DRY INSTRUCTIONS

Bath Towel Processing Requirements

OPERATION	TIME	WATER LEVEL	TEMP	SUPPLIES PER 100LB LOAD
1. Flush	3 minutes	High	100°F	---
2. Break	10 minutes	Low	160°F	8 oz. nonionic detergent & 16 oz. alkali
3. Suds	10 minutes	Low	160°F	4 oz. nonionic detergent
4. Bleach	8 minutes	Low	160°F	1 qt. 1% sodium hypochlorite
5. Rinse	3 minutes	High	145°F	---
6. Rinse	3 minutes	High	130°F	---
7. Rinse	3 minutes	High	115°F	---
8. Sour/Softener	3 minutes	Low	100°F	Sour to pH of 5.5 - 6.5

This formula is only a guideline. Alterations should be made at the discretion of the laundry professional based on specific requirements, supplies, equipment and experience.

DRYING

- Tumble at 160°F until dry and use an appropriate cool down cycle
- Do not overdry; hems should be "slightly" damp at the end of the drying cycle.
- Do not overload as the product should float freely in the dryer.

Softeners are recommended to maintain a soft hand, avoid overuse as they can have a negative affect on the absorbency performance.

Please feel free to contact the Technical Affairs Department of Standard Textile for any additional information